

Tastatura za Lenovo Thinkpad T14 G1 20S0 20S1 20S2 20S3 20UD 20UE osvetljenje

Šifra: hobo-74Z

Kategorija proizvoda: Tastaure za Lenovo

Proizvođač: Lenovo

Cena: **3.190,00** rsd.



Odgovara za model: 20S00004PG, 20S00005PG, 20S00006PG, 20S00007PG, 20S00008PG, 20S00009PG, 20S0000APG, 20S0000BPG, 20S0000CPG, 20S0000DPG, 20S0000EPG, 20S0000FPG, 20S0000GPG, 20S0000HPG, 20S0000JPG, 20S0000KPG, 20S0000LPG, 20S0000MPG, 20S0000NPG, 20S0000SPG, 20S0000TPG, 20S0000VPG, 20S0000WPG, 20S0000XPG, 20S0000YPG, 20S00010PG, 20S00011PG, 20S00012PG, 20S00013PG, 20S0001CPG, 20S00043PG, 20S00044PG, 20S00045PG, 20S00046PG, 20S00049PG, 20S0004APG, 20S0004BPG, 20S0004CPG, 20S0004MPG, 20S0004NPG, 20S0004PPG, 20S0004QPG, 20S00057PG, 20S00058PG, 20S0005DPG, 20S0005EPG, 20S0005FPG, 20S0005GPG, 20S0005VPG, 20S0005WPG, 20S0005XPG, 20S0005YPG, 20S00060PG, 20S00064PG, 20S00065PG, 20S00066PG, 20S00067PG, 20S0006DPG, 20S0006JPG, 20S0006KPG, 20S0006LPG, 20S0006MPG, 20S0006NPG, 20S0006QPG, 20S0006VPG, 20S0006WPG, 20S00073PG, 20S00074PG, 20S00075PG, 20S00076PG, 20S00077PG, 20S00078PG, 20S00079PG, 20S0007LPG, 20S0007PPG, 20S0008FPG, 20S0008GPG, 20S00099PG, 20S0009APG, 20S0009BPG, 20S1001GPG, 20S1001HPG, 20S1001JPG, 20S1001KPG, 20S1001MPG, 20S1001NPG, 20S1001PPG, 20S1001QPG, 20UD000XPG, 20UD000YPG, 20UD0010PG, 20UD0011PG, 20UD0012PG, 20UD0013PG, 20UD0014PG, 20UD0019PG, 20UD001APG, 20UD001BPG, 20UD001CPG, 20UD001DPG, 20UD001EPG, 20UD001FPG, 20UD001JPG, 20UD0026PG, 20UD002BPG, 20UD002CPG, 20UD002FPG, 20UD002GPG, 20UD002HPG, 20UD003NPG, 20UD003PPG, 20UD003QPG, 20UD003RPG, 20UD003SPG, 20UD003UPG, 20UD003VPG, 20UD003WPG, 20UD003XPG, 20UD003YPG, 20UD0040PG, 20UD0041PG, 20UD0042PG, 20UD0045PG, 20UD0047PG, 20UD004BPG, 20UD004CPG, 20UD004DPG, 20UD004EPG, 20UD004FPG, 20UD004GPG, 20UD0053PG, 20UD0054PG, 20UD0055PG, 20UD005FPG, 20UD005GPG, 20UD005HPG, 20UD005JPG, 20UD005KPG, 20UD005LPG, 20UD005MPG, 20UD005NPG, 20UD005PPG, 20UD005QPG, 20UD005RPG, 20UD005SPG, 20UD005TPG, 20UD005UPG, 20UD005VPG, 20UD005WPG, 20UD005XPG, 20UD005YPG, 20UD0060PG, 20UD0061PG, 20UD0062PG, 20UD0065PG, 20UD0066PG, 20UD0067PG, 20UD006CPG, 20UD006DPG, 20UD006EPG,

20UD006FPG, 20UD006GPG, 20UD006HPG, 20UE000BPG, 20UE000CPG, 20UE000DPG, 20UE000EPG,
20UE000FPG, 20UE000GPG, 20UE000HPG, 20UE000JPG

Part Number: 064009F, 0C20004, 23M0002, 2CH000T, 2H-ABEPTL70111, 2H-BBEPTL70111, 2H-BBEPTL70131,
5N20V43742, 5N20V43778, 5N20V43886, 5N20V43922, 5N20V44030, 5N20V44066, 5N20V44174,
5N20V44210, 5N20X68863, 5N20X70341, 5N21B08358, 5N21B08395, CMFBL-85P0, CMFNBL-85P0, JAZZ-UK85,
NBBE, NBLBE, PK131J51A19, PK131J53B19, PK131J5B19, PK131KH1B13, PK131KH2B19, PL131J53A19, POR 816,
PT 816, SG-95320-2PA, SG-A5660-2PA, SG-B3280-2PA, SN20V43670, SN20V43706, SN20V43814, SN20V43850,
SN20V43958, SN20V43994, SN20V44138, SN20X68505, SN20X68541, SN21B08210, SN439BBZ, SN5397BZ,
V170820DK3 P0