

Tastatura za Lenovo Thinkpad T14 G2 20W0 20W1 20XK 20XL osvetljenje

Šifra: hobo-74Z

Kategorija proizvoda: Tastaure za Lenovo

Proizvođač: Lenovo

Cena: **3.190,00** rsd.



Odgovara za model: 20W00003PG, 20W0000DPG, 20W0000EPG, 20W0000FPG, 20W0000GPG, 20W0000HPG, 20W0002TPG, 20W0002UPG, 20W0002VPG, 20W0002WPG, 20W0002XPG, 20W0002YPG, 20W00034PG, 20W00035PG, 20W00036PG, 20W00037PG, 20W00038PG, 20W0003APG, 20W0003CPG, 20W0003FPG, 20W0003GPG, 20W0003HPG, 20W0003XPG, 20W0003YPG, 20W00040PG, 20W00041PG, 20W00042PG, 20W00043PG, 20W00044PG, 20W00045PG, 20W00046PG, 20W00047PG, 20W00048PG, 20W00049PG, 20W0004APG, 20W0004BPG, 20W0004CPG, 20W0004DPG, 20W0004EPG, 20W0004FPG, 20W0004GPG, 20W0004HPG, 20W0004JPG, 20W0004KPG, 20W0004LPG, 20W0004MPG, 20W0004NPG, 20W0004PPG, 20W0004QPG, 20W0004RPG, 20W0004SPG, 20W0004VPG, 20W0004WPG, 20W0004XPG, 20W0004YPG, 20W00050PG, 20W00051PG, 20W00052PG, 20W00053PG, 20W00054PG, 20W00055PG, 20W00056PG, 20W00057PG, 20W0006TPG, 20W0006UPG, 20W0006VPG, 20W0006WPG, 20W0006XPG, 20W0006YPG, 20W00070PG, 20W00076PG, 20W00077PG, 20W0007LPG, 20W00092PG, 20W00093PG, 20W00094PG, 20W00095PG, 20W00096PG, 20W00097PG, 20W00098PG, 20W00099PG, 20W0009APG, 20W0009BPG, 20W0009CPG, 20W0009DPG, 20W0009EPG, 20W0009FPG, 20W0009GPG, 20W0009HPG, 20W0009JPG, 20W0009KPG, 20W0009LPG, 20W0009MPG, 20W0009NPG, 20W0009QPG, 20W0009TPG, 20W0009VPG, 20W0009WPG, 20W0009XPG, 20W000A1PG, 20W000A3PG, 20W000A4PG, 20W000A5PG, 20W000A6PG, 20W000A7PG, 20W000A8PG, 20W000A9PG, 20W000AAPG, 20W000ABPG, 20W000ACPG, 20W000ADPG, 20W000AEPG, 20W000AFPG, 20W000AGPG, 20W000AHPG, 20W000AJPG, 20W000AKPG, 20W000ALPG, 20W000AMPG, 20W000ANPG, 20W000APPG, 20W000AQP, 20W000ARPG, 20W000ASPG, 20W000ATPG, 20W000AUPG, 20W000AVPG, 20W000AWPG, 20W000AXPG, 20W000AYPG, 20W000B0PG, 20W000B1PG, 20W000B2PG, 20W000B3PG, 20W000B4PG, 20W000B5PG, 20W000B6PG, 20W000B7PG, 20W000B8PG, 20W000B9PG, 20W000BAPG, 20W000BBPG, 20W000BTPG, 20W000BUPG, 20W000BVPG, 20W000BWPG, 20W000CNP, 20W000DAPG, 20W000DBPG, 20W000DDPG, 20W000DEPG, 20W000DFPG, 20W000DGP, 20W000DHPG, 20W000DJPG, 20W000DKPG, 20W000DLPG, 20W000DMPG, 20W000DNPG, 20W000DPPG,

220W000DQPG, 220W000DRPG, 220W000DSPG, 220W000DTPG, 220W000DUPG, 220W000ECPG, 220W000EDPG, 220W000EEPG, 220W000EFPG, 220W000EGPG, 220W000EHPG, 220W000EJPG, 220W000ELPG, 220W000EMPG, 220W000EQPG, 220W000F1PG, 220W000F2PG, 220W000GLPG, 220W000GMPG, 220W000GNPG, 220W000GPPG, 220W000GQPG, 220W000GRPG, 220W000GSPG, 220W000GTPG, 220W000GUPG, 220W000GVPG, 220W000GWPG, 220W000GXPG, 220W000GYPG, 220W000H0PG, 220W000H1PG, 220W000H2PG, 220W000H3PG, 220W000H4PG, 220W000H5PG, 220W000H6PG, 220W000H7PG, 220W000H8PG, 220W000H9PG, 220W000HAPG, 220W000HBPG, 220W000HCPG, 220W000HDPG, 220W000HEPG, 220W000HFGP, 220W000HGGP, 220W000HHPG, 220W000HJPG, 220W000HKPG, 220W000HLPG, 220W000HMPG, 220W000HNPG, 220W000HPPG, 220W000HQPG, 220W000HRPG, 220W000HSPG, 220W000HTPG, 220W000HUPG, 220W000HVPG, 220W000HWPG, 220W000HXP, 220W000HYPG, 220W000J0PG, 220W000J1PG, 220W000J2PG, 220W000J3PG, 220W000J4PG, 220W000J5PG, 220W000J6PG, 220W000J7PG, 220W000J8PG, 220W000J9PG, 220W000JAPG, 220W000JBPG, 220W000JCPG, 220W000JDPG, 220W000JEPG, 220W000JFPG, 220W000JGPG, 220W000JHPG, 220W000JJP, 220W000JKPG, 220W000JLPG, 220W000JMPG, 220W000JNPG, 220W000JPPG, 220W000JQPG, 220W000JRP, 220W000JSPG, 220W000JTPG, 220W000JUPG, 220W000JVP, 220W000JWPG, 220W000JXPG, 220W000JYPG, 220W000K0PG, 220W000K1PG, 220W000K2PG, 220W000K3PG, 220W000K4PG, 220W000K5PG, 220W000K6PG, 220W000K7PG, 220W000K8PG, 220W000K9PG, 220W000KAPG, 220W000KBPG, 220W000KCPG, 220W000KDPG, 220W000KEPG, 220W000KFGP, 220W000KGGP, 220W000KHGP, 220W000KJPG, 220W000KKPG, 220W000KLP, 220W000KMJPG, 220W000MKPG, 220W000MLPG, 220W000MMPG, 220W000MNP, 220W000MPPG, 220W000MYP, 220W000NQPG, 220W000NRPG, 220W000NSPG, 220W000NTPG, 220W000NUP, 220W000NVP, 220W000NWP, 220W000NXPG, 220W000NYP, 220W000P0PG, 220W000P1PG, 220W000P2PG, 220W000P3PG, 220W000P4PG, 220W000P5PG, 220W000P6PG, 220W000P7PG, 220W000P8PG, 220W000P9PG, 220W000PAP, 220W000PBPG, 220W000PCPG, 220W000PDP, 220W000PEPG, 220W000PFGP, 220W000PGPG, 220W000PHGP, 220W000PJPG, 220W000PKPG, 220W000PLPG, 220W000PMPG, 220W000PNPG, 220W000PPG, 220W000PQPG, 220W000PRPG, 220W000PSPG, 220W000PTPG, 220W000PUPG, 220W000PVP, 220W000PXPG, 220W000PYPG, 220W000Q0PG, 220W000Q1PG, 220W000Q2PG, 220W000Q3PG, 220W000Q4PG, 220W000Q5PG, 220W000Q6PG, 220W000Q7PG, 220W000Q8PG, 220W000Q9PG, 220W000QAPG, 220W000QBPG, 220W000QFGP, 220W000QKPG, 220W000QQPG, 220W000QXPG, 220W000QYP, 220W000R0PG, 220W000R1PG, 220W000R2PG, 220W000RWP, 220W000TKPG, 220W000TLP, 220W000UCPG, 220W000UDPG, 220W000UEPG, 220W000UFGP, 220W000UGPG, 220W000UHP, 220W000UJPG, 220W000UKPG, 220W000ULPG, 220W000UMP, 220W000UNPG, 220W000UPG, 220W000UQPG, 220W000V5PG, 220W000V6PG, 220W000V7PG, 220W000V8PG, 220W000V9PG, 220W000VAP, 220W000VBPG, 220W000VCP, 220W000VDP, 220W000VEPG, 220W000VFGP, 220W000VGGP, 220W000VHP, 220W000VJPG, 220W000VKPG, 220W000VLP, 220W000VMPG, 220W000VNP, 220W000VPP, 220W000VQPG, 220W000VRPG, 220W000VSP, 220W000VTP, 220W000VUPG, 220W000VVP, 220W000VWPG, 220W000VXPG, 220W000VYP, 220W000W0PG, 220W000W1PG, 220W000W2PG, 220W000W3PG, 220W000W4PG, 220W000W5PG, 220W000W6PG, 220W000W7PG, 220W000W9PG, 220W000WAPG, 220W000WBPG, 220W000WCP, 220W000WDP, 220W000WEP, 220W000WFGP, 220W000WGPG, 220W000WHPG, 220W000WJPG, 220W000WKPG, 220W000WLP, 220W000WMP, 220W000WPP, 220W000WQPG, 220W000WRPG, 220W000WSP, 220W000WTP, 220W000WUPG, 220W000WVP, 220W000X0PG, 220W000X1PG, 220W000X2PG, 220W000X3PG, 220W000X4PG, 220W000X5PG, 220W000X6PG, 220W000X7PG, 220W000X9PG, 220W000XAPG, 220W000XBPG, 220W000XCP, 220W000XDP, 220W000XEP, 220W000XGPG, 220W000XHP, 220W000XLPG, 220W000XMP, 220W000XNP, 220W000XPP, 220W000XQPG, 220W000XTP, 220W000XWPG, 220W000XXPG, 220W000XYP, 220W000Y0PG, 220W000Y1PG, 220W000Y2PG, 220W000Y3PG, 220W000Y4PG, 220W000Y5PG, 220W000YMP, 220W000YNPG, 220W000YPP, 220W0011NPG, 220W0011PPG, 220W0011QPG, 220W0011RPG, 220W0011SPG, 220W0011TPG, 220W0011UPG, 220W0011VPG, 220W0011WPG, 220W0011XPG, 220W0011YPG, 220W00120PG, 220W00121PG, 220W00122PG, 220W00123PG, 220W00124PG, 220W00125PG, 220W00126PG, 220W00127PG, 220W00128PG, 220W00129PG, 220W0012APG, 220W0012BPG, 220W0012CPG, 220W0012DPG, 220W0012EPG, 220W0012FGP, 220W0012GGP, 220W0012HPG, 220W0012KPG, 220W0012LPG, 220W0012MPG, 220W0012NPG, 220W0012PPG, 220W0012QPG, 220W0012RPG, 220W0012SPG, 220W0012TPG, 220W0012UPG, 220W0012WPG, 220W0012XPG, 220W00130PG, 220W00132PG, 220W00133PG, 220W00135PG, 220W00136PG, 220W00137PG, 220W00138PG, 220W00139PG, 220W0013CPG, 220W0013DPG, 220W0013FGP, 220W0013JPG, 220W0013KPG, 220W0014APG, 220W0014BPG, 220W0014NPG, 220W0014PPG, 220W0014QPG, 220W0014RPG, 220W10000PG, 220W10001PG, 220W10002PG, 220W10003PG, 220W10004PG, 220W10005PG, 220W10006PG, 220W10082PG, 220W10083PG, 220W10084PG, 220W10085PG, 220W10086PG, 220W10087PG, 220W10088PG, 220W100D9PG. 220XK0006PG, 220XK0007PG, 220XK000MPG, 220XK000NPG, 220XK000YPG, 220XK0010PG, 220XK0011PG, 220XK0012PG, 220XK001LPG, 220XK001MPG, 220XK001NPG, 220XK001PPG, 220XK001XPG, 220XK001YPG, 220XK0020PG, 220XK0021PG, 220XK0022PG, 220XK002GPG, 220XK002HPG, 220XK002JPG, 220XK002KPG, 220XK002LPG, 220XK002MPG, 220XK002NPG, 220XK002PPG, 220XK002QPG, 220XK002RPG, 220XK002SPG, 220XK002TPG, 220XK002UPG, 220XK002VPG, 220XK002WPG, 220XK004GPG, 220XK004HPG, 220XK004JPG, 220XK004KPG, 220XK004QPG, 220XK004RPG, 220XK004SPG, 220XK005RPG, 220XK005SPG, 220XK006HPG, 220XK0078PG, 220XK0079PG, 220XK007APG, 220XK007CPG, 220XK007DPG, 220XK007EPG, 220XK007JPG, 220XK0096PG, 220XK0097PG, 220XK0098PG, 220XK0099PG, 220XK009APG, 220XK009BPG, 220XK009CPG, 220XK009DPG, 220XK009EPG, 220XK009FGP, 220XK009GPG, 220XK009HPG, 220XK009JPG, 220XK009KPG, 220XK009LPG, 220XK009MPG, 220XK009NPG, 220XK009PPG, 220XK009QPG,

20XK009RPG, 20XK009SPG, 20XK009TPG, 20XK009UPG, 20XK009VPG, 20XK009WPG, 20XK009XPG,
20XK009YPG, 20XK00A0PG, 20XK00A1PG, 20XK00A2PG, 20XK00A3PG, 20XK00A4PG, 20XK00A5PG,
20XK00A6PG, 20XK00A7PG, 20XK00A8PG, 20XK00A9PG, 20XK00AAPG, 20XK00ABPG, 20XK00ACPG,
20XK00ADPG, 20XK00AEPG, 20XK00AFPG, 20XK00AGPG, 20XK00B1PG, 20XL0012PG, 20XL0013PG,
20XL0014PG, 20XL0015PG, 20XL0016PG, 20XL0017PG, 20XL001SPG

Part Number: 064009F, 0C20004, 23M0002, 2CH000T, 2H-ABEPTL70111, 2H-BBEPTL70111, 2H-BBEPTL70131,
5N20V43742, 5N20V43778, 5N20V43886, 5N20V43922, 5N20V44030, 5N20V44066, 5N20V44174,
5N20V44210, 5N20X68863, 5N20X70341, 5N21B08358, 5N21B08395, CMFBL-85P0, CMFNBL-85P0, JAZZ-UK85,
NBBE, NBLBE, PK131J51A19, PK131J53B19, PK131J5B19, PK131KH1B13, PK131KH2B19, PL131J53A19, POR 816,
PT 816, SG-95320-2PA, SG-A5660-2PA, SG-B3280-2PA, SN20V43670, SN20V43706, SN20V43814, SN20V43850,
SN20V43958, SN20V43994, SN20V44138, SN20X68505, SN20X68541, SN21B08210, SN439BBZ, SN5397BZ,
V170820DK3 P0