

Tastatura za Lenovo ThinkPad T470 20HD 20HE 20JM 20JN osvetljenje

Šifra: hobo-136Z
Kategorija proizvoda: Tastaure za Lenovo
Proizvođač: Lenovo

Cena: **3.190,00** rsd.

Part Number: 8930006, 9350007, 01AX386, 01AX427, 01AX468, 01AX509, 01AX550, 01AX591, 01HX320, 01HX360, 01HX400, 01HX440, 01HX480, 01HX520, 767001C, 844008Z, 84B0053, 8AF000G, 8AS0006, 95N0007, 9BF0004, 9Z.NDBBT.006, 9Z.NDBBT.B01, A004, A006, FU53601, FU5360BL, LIM16C16PO-G62A, LIM16C16PO-G62A, NBL-PT, NSK-ZB0BT, NSK-ZB0BT 06, NSK-ZB0ST 06, PK1312D2A22, PK1312D2B22, PK1312D4B22, SG-85510-2PA, SN20L72695, SN20L72748, SN20L72789, SN20L72830, SN20L72871, SN20L72912, SN20L72B71, SN20P41662, SN20P41702, SN20P41782, SN20P41822, SN20P41862, SN5360, SN5360BL, SN5360BL1, WIDBL-85P0, WIDNBL-85P0, Windu NBL-PT, Windu2 BL-PT, WinduBL-PT, WinduMBL-PT

Odgovara za modele: 20HD0000PG, 20HD0001PG, 20HD0002PG, 20HD000DPG, 20HD000EPG, 20HD000LPG, 20HD000MPG, 20HD000NPG, 20HD000PPG, 20HD001BPG, 20HD001CPG, 20HD001DPG, 20HD001EPG, 20HD001FPG, 20HD002HPG, 20HD002JPG, 20HD002KPG, 20HD003SPG, 20HD003TPG, 20HD0043PG, 20HD0048PG, 20HD0049PG, 20HD0054PG, 20HD0055PG, 20HD005NPG, 20HD005PPG, 20HD005QPG, 20HD005RPG, 20HD005SPG, 20HD0062PG, 20HD0065PG, 20HD006GPG, 20HD0074PG, 20HDA02GPG, 20HE0053PG, 20HE0054PG, 20HE0055PG, 20JM0000PG, 20JM0008PG, 20JM0015PG, 20JM0016PG, 20JN000GPG, 20JN000HPG, 20JN000JPG